

PULITORE CERCHI ORI MAX

Concentrated acid detergent



AVAILABLE FORMAT

Item	Format
220776	kg 10
220775	kg 26

REV. 5/22-10-2025

USE

To clean wheel rims: dilute the product to 18-25%.

For cleaning aluminium parts: dilute the product to 3-5% (increase the concentration based on the type of dirt).

Mist spray the diluted solution on the area, wait a few minutes and then rinse at high pressure.

CAUTION: Avoid using the product on hot wheel rims. Do not allow the product to dry on the part before rinsing it off. Given the different types of alloys and aluminium available on the market, it is advisable to carry out a preliminary test (in a small, hidden area) to check the compatibility of the product.

PHYSICAL-CHEMICAL CHARACTERISTICS

Chemical classification	Non-ionic solution
Physical state	Liquid
Solubility in water	In every ratio
Color	Colourless
pH	1 ± 1
Density	1,203 ± 0,020 g/ml

Refer to the safety data sheet for hazard information and precautions.

USAGE

Fast-acting product with an acid base, specially designed for cleaning alloy and metal wheel rims. It acts very quickly, performing a triple descaling, derusting and de-oxidising action. PULITORE CERCHI ORI MAX is also used for reconditioning side rails, platforms and other aluminium parts.

